



Spreader V3 Quick Start Version 302



PRECISION
AGRONOMICS AUSTRALIA


www.i4m.tech

admin@precisionag.com.au




Leave the hopper empty until the setup is done

Installation – Tractors with ISO Socket



- Install the button switch in the cab
- Plug the harness to the ISO socket
- The ISO socket is for power only, it is not connected to the ISOBUS
- The GPS will auto connect to the control box WIFI

Installation – Tractors without ISO Socket



- Install the button switch in the cab
- Connect the power harness to 12volts and ground
- Use switched power (power is off when the tractor key is off)
- If you connect to the battery, unplug the spreader cable when not using the spreader
- The GPS will auto connect to the control box WIFI

Power On

- The controller and GPS take 5 seconds to boot up
- Both boxes have LEDs



Connect Hydraulics



- Setup as shown below

Single remote
Adjust hyd flow to set spinner RPM

Belt flow will be OK

Dual remotes
Adjust hyd flow to set spinner RPM

Adjust belt flow to approx 40%
Increase it later if belt is too slow
Too much flow will overheat



Get the Android App

- Connect to the internet
- Scan the code
- Or Google i4M
- Tap Support > Spreader > i4M-Version3 > Download-App > Select the bottom file
- Tap Open (or go to downloads folder and tap the file)
- Tap Install
- “Trust this app” or “Unsafe app” messages Tap More > Tap Install anyway
- Done



Machine Setup

- Tap the menus below



Belt slip alert ✓

Machine has electric door actuator ✓

Belt and door options

Check these settings
Tap Belt and door options
Tap More info...




This machine has loadcells ✓

Calibrate the loadcells

Check these settings
Calibrate if not already done

Product Setup

- Tap the menus below




Using the work screen

- Tap the menus below



Show hopper kg on your phone

- Watch the hopper kg when you're filling the spreader
- Put your phone in airplane mode (or turn off mobile data)
- Connect to MACHINE WIFI
- Open your internet browser
- Enter this address 192.168.50.50



Get more info and help

- Connect to the internet
- Scan the code
- Or Google i4M
- Tap Support > Spreader > i4M-Version3

