Technote 19010

i4M Controller Powerup and Connection Issues

05.06.20

Symptoms

LED does not illuminate

LED light is intermittent


Device will not connect to WIFI

Connects to WIFI but can't change settings or use i4M app

LED light stays red

LED diagnostic light is located on the underside of the controller as shown below

i4M VRT or MONITOR ONLY:



Notes

Ensure latest version of i4M app is installed Ensure your device (Tablet, iPad) software is up to date Ensure controller is receiving clean and constant 12V power If LED light is stuck on red, contact the factory

If your machine is equipped with an MDC Monitor controller, your 2 LED's will be red and blue as shown below

MDC MONITOR CONTROLLER:

